

How to Format an SD Card – Insta 360 X3

1. Press the Power button once to turn on.




2. Swipe the screen down to open menu, tap Settings icon.




3. Scroll down menu and tap SD card.

4. Tap format, confirm.



then tap the tick box to



5. Insta 360 will buzz when finished.

6. Hold the Power button for 2 seconds to turn off.